



Arlington Ind. Inc.
1 Stauffer Ind. Park
Scranton, Pa.
800-233-4717
Fax 570-562-0646

Installation Instructions for FBR415F/FBR425F/FBR423 Fan/Fixture Box W/ Adjustable Bracket

1. Loosen the center screw in base of box to adjust bracket.
2. Select desired location for fan/fixture box. Adjustable for joist or rafters 16" to 24" on centers.
3. Temporarily attach bracket by hammering bent spike into joist.
4. Secure bracket with four #12 x 1" hex head screws. Install 2 at each end of bracket mounting area.
5. Locate box to desired position on bracket. When box is located re-tighten center screw.
6. Install non-metallic cable through connector provided. Replace mud cover.
7. When installing fan or fixture use 2 (parked-in-place) #10-32 hex head screws. Cable installation as per NEC, local code and manufacturer's instructions.